

CHAFING DISH INSTRUCTIONS

1. Use only Sterno type fuel in chafer burner.
2. Never light the burner before putting water in the water pan.
3. To speed the warming process, start with warm water. Always ensure an adequate supply of water is kept in the water pan.
4. Do not place chafer on a hot stove element or open flame.
5. Stainless steel FOOD pans can be used for cooking and may be placed in an oven to cook or keep food warm.
6. Do not place plastic wrap over the food pans! It melts to the pans. This will cause us to sell the pan(s) to you.
7. **NEVER** use the chafer without water!
8. Please remove all food from pan(s) and fuel from the cup(s) prior to return. It is not necessary to wash the pan; however, they must be well rinsed.

If you have any difficulties with the equipment, please call as soon as possible for assistance.

360-754-7365

Thank you for including Celebrations in your event.