

# THE QUEBBIE

## **TO CONNECT:**

1. Connect the power cord to the back of the Quebbie
2. Connect the audio cables to the back of the Quebbie. Audio cables MUST be pushed firmly for complete connection, they are a tight fit.
3. Plug the Quebbie into the backup power supply. Make sure that the Quebbie is plugged into the side of the box marked “backup power supply”.
4. Plug the audio cable into the Pro Sound System on the front in line 5
5. Plug the speaker cables into the respective outlets on the speakers, then into the Pro Sound System on the back.
6. Plug the p.a. system into the power strip. (Not the backup power supply!!!)
7. Plug the backup power supply into the power strip.
8. Plug the power strip into the wall outlet.
9. Secure all cords and make sure there is no trip hazard across the floor.
10. Turn the power switch on the power strip on.
11. Press the power switch on the backup power supply.
12. Press the power button on the front of the Quebbie. (It takes the Quebbie several seconds to power up and become active.)
13. Adjust your mixer levels for optimum sound.
  - a. Reverb should always be on the lowest setting.
  - b. Line 5 level should be set to at least to middle.
  - c. Line 1 should be your microphone. Keep this level at the lowest setting until you need to use it. This helps eliminate feedback.

The Quebbie is now ready to play your selections. Should you need help, simply press the help button on the screen of the Quebbie

## **TO SHUT DOWN:**

1. Press “clear play list”
2. Press “shut down”
3. Turn the power switch off on the p.a. system.
4. When the Quebbie has shut down and the red light is on, push the power button on the backup power supply.
5. Turn the power strip off.
6. You may now disconnect the cords, and roll them up for transport.
7. Replace the face shield on the Quebbie before loading it for transport.

## **TROUBLE SHOOTING TIPS:**

1. The most common problem is “No Sound”-
  - a. First check to make sure that your audio cables are COMPLETELY in.
  - b. Check your line 5 level, adjust to a higher setting.
  - c. Check your master volume control, adjust to a higher setting.
  - d. Make sure you have a song in the Que.
  - e. Make sure the Pro Sound System is plugged in and turned on.
2. Feedback-
  - a. Check line 1, and reduce the level.
  - b. Move the microphone away from the speakers
3. Quebbie won't turn on-
  - a. Make sure power cord is connected to Quebbie
  - b. Make sure power cord is connected to UPS battery backup
  - c. Make sure UPS battery backup is connected to power strip
  - d. Make sure power strip is connected to a power source

- e. Make sure Quebbie is turned (switch at the back of the Quebbie)
- f. Make sure the UPS battery backup is turned on (power button on the front)

**SHOULD YOU EXPERIENCE A PROBLEM WITH YOUR QUEBBIE, PLEASE CALL US IMMEDIATELY AT 360-754-7368.**

Thank you for including Celebrations in your event!